

MOUNTING GASKETS & O-RINGS

WASTEGATES	Qty. Ex. Gasket	P/N Gasket	Alt. P/N	Alt. P/N
470908 Series	2 each	652456	9910306-1	24096-225
470780 Series	2 each	652456	9910306-1	24096-225
481064 Series	2 each	652456	9910306-1	24096-225
470954 Series	2 each	652456	9910306-1	24096-225
470818 Series	2 each	75845	SL75845	
470842 Series	2 each	652457	1550148-2	
470830 Series 3 inch	2 each	24096-300N	2176-300N	
470830 Series 2 inch	2 each	24096-200N	2176-200N	SL78083
All units require: 2 each) MS29513-04 & 1 each) MS29512-06 O-Rings				

PRESSURE RELIEF VALVE	Qty. O-Ring	P/N O-Ring		
470930 Series	1 each	MS29513-138		
470944 Series	1 each	MS29513-138		

VARIABLE ABSOLUTE PRESSURE CONTROLLER	Qty. Gasket	P/N Gasket	Qty. O-Ring	P/N O-Ring
470836 Series wo/Cover	1 each	653333	2 each	MS29512-06
470924 Series wo/Cover	1 each	653333	2 each	MS29512-06
481008 Series wo/Cover	1 each	653333	2 each	MS29512-06
481012 Series w/Cover	N/A	N/A	3 each	MS29512-06

ABSOLUTE PRESSURE CONTROLLER	Qty. O-Ring	P/N O-Ring		
470616 Series	2 each	MS29512-06		
470688 Series	2 each	MS29512-06		
SLOPED CONTROLLER				
481058 Series				
All units require: 3 each) MS28512-06, 1 each) MS29512-04 & 1 each) MS29512-08 O-Rings				

DENSITY CONTROLLER	Qty. Gasket	P/N Gasket	Qty. O-Ring	P/N O-Ring
470620 Series	1 each	SL73314	2 each	MS29512-06
470654 Series	1 each	SL73314	2 each	MS29512-06
470884 Series	1 each	SL73314	2 each	MS29512-06

RATIO/ABSOLUTE DUAL CONTROLLER				
470948 Series				
470934 Series				
All units require: 3 each) MS29512-06 & 1 each) MS29512-08 O-Rings				

DIFFERENTIAL PRESSURE CONTROLLER	Qty. Gasket	P/N Gasket	Qty. O-Ring	P/N O-Ring
470912 Series w/Cover	N/A	N/A	3 each	MS29512-06

470886 Series wo/Cover	1 each	SL73314	2 each	MS29512-06
All units also require: 1 each) MS29512-08				

RATE CONTROLLER				
470838 Series				
All units require: 2 each) MS29152-06 & 1 each) MS29512-08 O-Rings				

PRESSURE RATIO CONTROLLER				
470822 Series				
All units require: 2 each) MS29512-06 & 1 each) MS29512-08 O-Rings				

This chart is for informational purposes only and it is the installers responsibility to verify proper part numbers for their specific application before installing.